






















www.CabanaCoast.com

- | | | | |
|---|---|--|---|
| <input type="checkbox"/> 3008-0031 Chorus DP 44" W x 44" D x 34" H | <input type="checkbox"/> 3007-0011 Large Deep Seating 38" W x 40" D x 37" H | <input type="checkbox"/> 3007-0019 Wicker Dining 29" W x 29" D x 39" H | <input type="checkbox"/> 3008-0037 Chorus Rd. Daybed 81"W x 81"D x 36"H |
| <input type="checkbox"/> 3008-0032 Chorus LS 74" W x 44" D x 34" H | <input type="checkbox"/> 3007-0012 Large Loveseat 62" W x 40" D x 37" H | <input type="checkbox"/> 3008-0049 Bar Chair/Stack Chair 28" W x 28" D x 53" H | <input type="checkbox"/> 3008-0062 XL Curved Sofa 169"W x 40"D x 37"H |
| <input type="checkbox"/> 3008-0033 Chorus SF 105" W x 44" D x 34" H | <input type="checkbox"/> 3007-0013 Large Sofa 86" W x 40" D x 37" H | <input type="checkbox"/> 3007-0022 Chorus Lounge Armless 32" W x 85" D x 18" H | <input type="checkbox"/> 3008-0061 Curved Sofa 116"W x 40"D x 37"H |
| <input type="checkbox"/> 3008-0034 X Large Deep Seating 40" W x 42" D x 42" H | <input type="checkbox"/> 3007-0015 Deep Seating 32" W x 34" D x 36" H | <input type="checkbox"/> 3007-0023 Chorus Sq. Daybed 56" W x 82" D x 20" H | <input type="checkbox"/> 3007-0026 Cbana Daybed 62"W x 90"D x 80"H |
| <input type="checkbox"/> 3008-0035 X Large Loveseat 65" W x 42" D x 42" H | <input type="checkbox"/> 3007-0016 Loveseat 56" W x 34" D x 36" H | <input type="checkbox"/> 3007-0024 W/Arm Lounge 33" W x 86" D x 27" H | |
| <input type="checkbox"/> 3008-0036 X Large Sofa 92" W x 42" D x 42" H | <input type="checkbox"/> 3007-0014 Bimini Daybed 91" W x 51" D x 28.5" H | <input type="checkbox"/> 3007-0025 W/Arm Double Lounge 59" W x 83" D x 27" H | |

| Description | Item | SIZE | Size Detail | | | | |
|-------------------------|-----------|---------------------------|---|--|--|--|---|
| Chorus DP cover | 3008-0031 | 44" W x 44" Deep x 34" H |  | | | | |
| Chorus LS cover | 3008-0032 | 74" W x 44" Deep x 34" H |  | | | | |
| Chorus SF cover | 3008-0033 | 105" W x 44" Deep x 34" H |  | | | | |
| Chorus Rd. Daybed Cover | 3008-0037 | 81"W*81"D*36"H |  | | | | |
| X Large Deep Seating | 3008-0034 | 40" W x 42" Deep x 42" H |  | | | | |
| X Large Loveseat | 3008-0035 | 65" W x 42" Deep x 42" H |  | | | | |
| X Large Sofa | 3008-0036 | 92" W x 42" Deep x 42" H |  | | | | 1 |

| | | | | | | | |
|--------------------|-----------|----------------------------|---|--|--|--|---|
| Large Deep Seating | 3007-0011 | 38" W x 40" Deep x 37" H |  | | | | |
| Large Loveseat | 3007-0012 | 62" W x 40" Deep x 37" H |  | | | | |
| Large Sofa | 3007-0013 | 86" W x 40" Deep x 37" H |  | | | | |
| Bimini Daybed | 3007-0014 | 91" W x 51" Deep x 28.5" H |  | | | | |
| Deep Seating | 3007-0015 | 32" W x 34" Deep x 36" H |  | | | | |
| Loveseat | 3007-0016 | 56" W x 34" Deep x 36" H |  | | | | |
| Chorus Sq. Daybed | 3007-0023 | 56" W x 82" Deep x 20" H |  | | | | 2 |

| | | | | | | | |
|-----------------------------|-----------|--------------------------|--|--|--|--|--|
| Chorus Lounge Armless | 3007-0022 | 32" W x 85" Deep x 18" H |  | | | | |
| W/Arm Double Lounge | 3007-0025 | 59" W x 83" Deep x 27" H |  | | | | |
| W/Arm Lounge | 3007-0024 | 33" W x 86" Deep x 27" H |  | | | | |
| Bimini Dining Chair Cover | 3007-0019 | 28" W x 28" Deep x 39" H |  | | | | |
| Bar Chair/Stack Chair Cover | 3007-0049 | 28" W x 28" Deep x 53" H |  | | | | |